



EgRO NEXT Touch Coffee 4 Hopper

Daily Coffee Cleaning



On the upper right corner of main screen, tap the Cleaning and Settings icon in the top right corner. Select the Operator Menu and enter the password 1234.



Select the Coffee cleaning. Continue following the on-screen instructions throughout the cleaning.



Remove the coffee grounds bin. Empty the bin, wipe clean, and replace in the machine.



Insert 1 Egro Coffee Machine Cleaning tablet into either of the chutes on the top of the machine. To unlock the chute, rotate the dial counterclockwise. After inserting the tablet, turn the dial clockwise to lock.



Caution: The machine will dispense HOT water from the drink spout.

When the cleaning is done, clean the drip tray with clean wet towel. The machine is now ready for use.



DO NOT SHUT THE MACHINE OFF DURING CLEANING!

It will cause the machine to become disabled and your warranty may be voided.

Shutting off the machine will NOT reset the cleaning counter. The only way to unblock a machine that has been blocked due to lack of cleaning is to perform the complete daily cleaning.

Cleaning Product Re-Order Information

To re-order the Egro Coffee Machine Cleaning Tablets, please send your orders to: orders@ranciliogroupna.com



Egro Coffee Machine Cleaning Tablets
Product # 69000427

We offer an Auto-Ship Cleaning Supplies Program to automatically ship cleaning products to you. Call (630) 914-7900 to learn more about our program.